

FX0608		Suitable for:	#
Pentagon socket	10	Citroën, Peugeot, Renault, Opel	001
	12.5	Citroën, Peugeot, Renault, Opel	002
	14	Smart Car and also Vauxhall Astra-G, Zafira	003
	19	Citroën, Peugeot, Renault (Bendix)	004
10PT	11.5	Porsche	005
	14	Audi	006
	15	Audi Q7, S8 & Porsche Macan, Cayenne, Cayman	007
	20	Audi A8, S6 & Porsche Cayenne	008
7PT	20	Audi Q7, S4	009
	AS-22	Audi S5	010
Hex Long	9	BMW & Mercedes-Benz	011
	7	BMW3/5 with E36 chassis, Ford Mondeo, Fiesta, Alfa Romeo, Vauxhall, Volkswagen, Saab, Chrysler, BMW, MINI	012
	7	BMW3/5 with E36 chassis, Ford Mondeo, Fiesta, Alfa Romeo, Vauxhall, Volkswagen, Saab, Chrysler, BMW, MINI	013
	11	Mercedes-Benz ML, Ford Focus & Edge brake caliper	014
Hex	H9	Mercedes-Benz ML320	015
	H8	Mercedes-Benz C Class, Audi TT (from 2007), A4 (from 2001), A6 (from 2005), A8 (from 2003).	016
	H7	Mercedes-Benz C Class, Audi TT (from 2007), A4 (from 2001), A6 (from 2005), A8 (from 2003).	017
Pentagon	10	Girling remmen	018
5PT Spline		EPB Golf 8 en equivalenten	019